



Appendix A Jumper Configuration

note: You only need to set the Jumper when the Card is in Jumper mode.

The Product can be configured by either jumper settings or software. Please refer to the table below for detail description of the jumper usage.

■ Hardware Jumper Setting



JP1 : 8 OPEN : Jumperless/PnP mode
CLOSE : Jumper mode

Note : Default is Jumperless/PnP Mode.